


# LOCK INSTRUCTIONS



Lock used on the following collections: CHILL DLX, AICON, CHILL PALM, SPARKLE, HAVÄNG, CHILL, ARTIC

The original number is 0-0-0. To set your personal combination, follow these steps:


1. Put the dials at its original numbers 0-0-0;
2. Press down the reset button (A) with a tool until hear the “click” sound.
3. Set your combination by turning the dials (B),for example 8-8-8. Then,
4. Push the button (C) towards to the direction of arrow and the reset button (A) will be back when you hear the “Click” sound

Now you have finished to set your personal combination.

Please remember your personal combination by heart.

Please repeat the above steps to reset the numbers.

# LOCK INSTRUCTIONS



Lock used on the following collections: DELPHI, FALSTERBO, KIVIK, PASADENA, ENROTE

The original number is 0-0-0. To set your personal combination, follow these steps:


1. Put the dials at its original numbers 0-0-0;
2. Press down the reset button (A) with a tool until hear the “click” sound.
3. Set your combination by turning the dials (B), for example 8-8-8. Then,
4. Push the button (C) towards to the direction of arrow and the reset button (A) will be back when you hear the “Click” sound

Now you have finished to set your personal combination.

Please remember your personal combination by heart.

Please repeat the above steps to reset the numbers.

# LOCK INSTRUCTIONS



Lock used on the following collections: MALIBU from 2019/08

The original number is 0-0-0. To set your personal combination, follow these steps:


1. Put the dials at its original numbers 0-0-0;
2. Press down the reset button (A) with a tool until hear the “click” sound.
3. Set your combination by turning the dials (B),for example 8-8-8. Then,
4. Push the button (C) towards to the direction of arrow and the reset button (A) will be back when you hear the “Click” sound

Now you have finished to set your personal combination.

Please remember your personal combination by heart.

Please repeat the above steps to reset the numbers.

# LOCK INSTRUCTIONS




Lock used on the following collections: ÅHUS

The present combination is 0-0-0 and can be personalized by following these simple steps:

1. Turn the dials to the current opening combination.
2. Press down the Reset Button (A) with a pen or other tools, after then turn the Dials (B) to your desired combination.
3. The lock is now set to the desired combination after you released the Reset Button (A) by pushing the Button (C).

You may change your combination and reset your lock again by following the above steps. Keep your personal combination in a safe place for future reference.

# LOCK INSTRUCTIONS




Lock used on the following collections: ÅHUS 2.0

The present combination is 0-0-0 and can be personalized by following these simple steps:

1. Turn the dials to the current opening combination.
2. Press down the Reset Button (A) with a pen or other tools, after then turn the Dials (B) to your desired combination.
3. The lock is now set to the desired combination after you released the Reset Button (A) by pushing the Button (C).

You may change your combination and reset your lock again by following the above steps. Keep your personal combination in a safe place for future reference.

# LOCK INSTRUCTIONS



Lock used on the following collections: MALIBU up to 2019/07

The original number is 0-0-0. To set your personal combination, follow these steps:


1. Put the dials at its original numbers 0-0-0;
2. Press down the reset button (A) with a tool until hear the “click” sound.
3. Set your combination by turning the dials (B),for example 8-8-8. Then,
4. Push the button (C) towards to the direction of arrow and the reset button (A) will be back when you hear the “Click” sound

Now you have finished to set your personal combination.

Please remember your personal combination by heart.

Please repeat the above steps to reset the numbers.

# LOCK INSTRUCTIONS



Lock used on the following collections: SWIFT

The original number is 0-0-0. To set your personal combination, follow these steps:


1. Put the dials at its original numbers 0-0-0;
2. Press down the reset button (A) with a tool until hear the “click” sound.
3. Set your combination by turning the dials (B),for example 8-8-8. Then,
4. Push the button (C) towards to the direction of arrow and the reset button (A) will be back when you hear the “Click” sound

Now you have finished to set your personal combination.

Please remember your personal combination by heart.

Please repeat the above steps to reset the numbers.

# LOCK INSTRUCTIONS



Lock used on the following collections: KNISLINGE

The original number is 0-0-0. To set your personal combination, follow these steps:

1. Put the dials at its original numbers 0-0-0;
2. Press down the reset button (A) with a tool until hear the “click” sound.
3. Set your combination by turning the dials (B),for example 8-8-8. Then,
4. Push the button (C) towards to the direction of arrow and the reset button (A) will be back when you hear the “Click” sound


Now you have finished to set your personal combination.

Please remember your personal combination by heart.

Please repeat the above steps to reset the numbers.



# LOCK INSTRUCTIONS



Lock used on the following collections: DURAMO

The original number is 0-0-0. To set your personal combination, follow these steps:

1. Put the dials at its original numbers 0-0-0;
2. Press down the reset button (A) with a tool until hear the “click” sound.
3. Set your combination by turning the dials (B),for example 8-8-8. Then,
4. Push the button (C) towards to the direction of arrow and the reset button (A) will be back when you hear the “Click” sound

Now you have finished to set your personal combination.

Please remember your personal combination by heart.

Please repeat the above steps to reset the numbers.